Cautionary Notes and Warnings

Important Handling Cautions and Warnings

Always handle your torque gauge with care.

Damage caused by improper handling is not covered under warranty.



DO NOT let the torque gauge fall or drop onto the ground!



DO NOT pass or handle liquids near the torque gauge to prevent spillage and liquid damage!

Always align the torque gauge shaft to the object measured, to prevent the shaft from warping and damaging the device!




DO NOT attempt to measure the torque of an object that is submerged in a liquid

Never use the torque gauge if there is an object or material wedged between the measuring rod and frame!

Cautionary Notes and Warnings

Cautionary Notes and Precautions








Keep safe distance from the load cell. Always use safety gloves, safety glasses and other protective gear.



Always keep the torque gauge and the power supply from water or other liquids.



Damaged batteries must be handled with extra care. Use rubber gloves and safety glasses. Dispose only in designated recycling centers.



Always disable charging before installing disposable batteries Charging non-rechargeable, alkaline batteries can be hazardous and cause damage to the torque gauge.

CAUTION:

- The torque gauge is designed for indoor use only.
- Do not operate the torque gauge in hazardous areas or under dangerous conditions.



- Do not connect cables in ways other than those mentioned in this manual.
- Never stand on or lean on this product. Equipment may fall or collapse, causing breakage and possible injury.
- Before moving the product, unplug it and unplug all cables connected to it.
- When storing, transporting or returning the torque gauge for service, always use the original packaging.

WARNING:



- Never attempt to repair, disassemble or modify the torque gauge. Tampering with the torque gauge may result in injury and cause greater damage to the equipment.
- Be sure to use the specified power source.
- Do not allow foreign matter to fall onto the torque gauge.
- If water or other liquid spills onto the torque gauge, unplug the power cord immediately and contact technical support.



Disposal of electronic equipment in waste containers is forbidden by law.

Cautionary Notes and Warnings

Important Mounting and Installation Cautions



- Torque Gauge Capacity must always exceed the predicted measurement load.
- Elements or parts used in mounting that are not supplied with the torque gauge, such attachments attachments, convertors, adapters, or bolt, must withstand torque of no less than 150% of torque gauge capacity.

Warning!

Custom attachment, adatpters, or mounting bolts and other connection hardware or elements not supplied with the torque gauge must sustain loads of at least 150% of torque gauge capacity. Any bolt or nut must be precisely matched to the diameter of loadcell socket or opening.